



# Location of Serial Numbers



predator Serial Number



  
P = Super Steer Model  
AN = Auto Nav Model

Predator Serial Number is located here above the Warning Label



Winch Serial Number is located here above the Fishtex Logo

